

104-30 Midget Body & Cage

Build Guide (25.01.21.01)

1. Assemble Cage by Attaching the following components... be sure to “sandwich” the side panels during the next steps... panel sets sold separately.
 - a. Attach NERF BARS to each SIDE PANEL (4x M3x12 FH)
 - b. Attach HEADERS to each SIDE PANEL (4x M3x12 FH)
 - c. Attach CAGE HOOD (6x M3x16)
 - d. Attach H-BAR (4x M3x16)
 - e. Attach 3 BARS (6x M3x16)
 - f. Attach CAGE FRONT with rounded edge forward and up (4x M3x16)
2. Attach Scoop to thru bottom of CAGE FRONT (4x M3x5)
3. Place the CAGE WEDGE, single hole up, on top of the Cage Hood and snug against the front of the Cage Front. Fasten by placing screws thru the bottom of the Cage Hood upwards into the wedge. (2x M3x12)
4. Attach Hood Panel to Cage Hood & Cage Front (8x M3x5)
 - a. the panel will be flexed to form a curved surface.
 - b. Install 2 screws in forward wide-spaced holes in Cage Front.
 - c. Install 2 screws in narrow-spaced holes on the Cage Hood just behind the front keyhole.
 - d. Install 2 screws in narrow-spaced holes on the Cage Hood in front of the keyhole.
 - e. Install 2 screws in rear wide-spaced holes in Cage Front.
5. Attach Rear MOUNT to top of H-Bar (2x M3x12)
6. Attache DRIVER PLATE to bottom of H-Bar (2x M3x12)
7. Install final 2x M3x5 screws in side panels lower front area

CONTENTS:

- 1) 104-32 Cage Right Side
- 2) 104-31 Cage Left Side
- 3) 104-004 Cage Hood
- 4) 104-003 Cage H-Bar
- 5) 104-001 Cage Bar
- 6) 104-009 Nerf Bar
- 7) 104-006 Headers
- 8) 784-04 Scoop
- 9) 104-008 Rear Mount
- 10) 104-005 Driver Plate
- 11) 104-002 Cage Front
- 12) 104-010 Cage Wedge

Screw Set

M3 x 16mm BH (16)
M3 x 12mm BH (6)
M3 x 5mm BH (14)
M3 x 12mm FH (8)

Panel Set (Sold Separately)
104-33 Left Side Panel
104-34 Right Side Panel
104-35 Hood Panel

Tank (Sold Separately)
784-05



